

HYUNDAI

POWER PRODUCTS

HCS58L & HCS65P

Ref	Description	HCS58L	HCS65P	Part number
2	Handle	*	*	HY00203
3	Starter cover only	*	*	HY00301
4	Small coil spring	*	*	HY00401
6	Pull rope	*	*	HY00602
7	Rope pulley	*	*	HY00702
8	Big coil spring	*	*	HY00802
10	Pulley cover	*	*	HY01001
11	Washer 5*16*1.5	*	*	HY01101
13	Wind guide cover	*	*	HY01301
14	Oil cap	*	*	HY01401
15	Oil cap washer	*	*	HY01501
16	Sprocket gasket	*	*	HY01602
21	Flywheel	*	*	HY02107
24	Seat of damping spring	*	*	HY02401
25	Tap Screw 5*16	*	*	HY02501
26	Damping spring	*	*	HY02601
30	Left case	*	*	HY03005
34	Suction mouth	*	*	HY03401
39	Cylinder paper pad	*	*	HY03904
40	Piston ring	*		HY04009
	Piston ring		*	HY04005
44	Piston, pin & spring	*		HY04406
	Piston, pin & spring		*	HY04404
45	Antiwear gasket	*	*	HY04501
46	Needle bearing 11*15*12.5	*	*	HY04607
47	Wood ruff key 3*10	*	*	HY04701
48	Crank shaft	*		HY04810
	Crank shaft		*	HY04809
49	Cylindrical pin 5*10	*	*	HY04905
50	Crank case paper pad	*	*	HY05006
51	Right case	*	*	HY05105
55	Air Vent	*	*	HY05501
61	Engine Oil filter	*	*	HY06101
62	Chain block	*	*	HY06202
63	Oil outlet pipe	*	*	HY06301
64	Double-thread screw	*	*	HY06402
65	Oil deflector	*	*	HY06501
67	Engine oil pump	*	*	HY06701
70	Gear cover	*	*	HY07001
71	Worm gear	*	*	HY07102
72	Needle bearing 10*14*10	*	*	HY07202

73	Sprocket	*	*	HY07301
74	Clutch drum	*	*	HY07401
75	Clutch gasket	*	*	HY07501
76	Clutch	*	*	HY07601
79	Felling dog	*	*	HY07901
80	Sprocket metal guarder	*	*	HY08001
83	Main lever	*	*	HY08301
84	Movable block	*	*	HY08401
85	Movable block jacket	*	*	HY08502
86	Brake band	*	*	HY08602
87	Straight pin 3*8	*	*	HY08701
91	Movable block spring	*	*	HY09102
92	Tension plate	*	*	HY09201
97	Sprocket plastic guarder	*	*	HY09701
100	circlip 8	*	*	HY10001
107	Fuel tank	*	*	HY10708
108	Switch rod	*	*	HY10803
109	Back handle cover	*	*	HY10901
110	Fuel filter	*	*	HY11001
112	Copper filter	*	*	HY11201
113	Throttle push rod	*	*	HY11301
114	Fuel pipe	*	*	HY11401
115	Throttle button	*	*	HY11504
116	Torsion spring of switch	*	*	HY11601
117	Cylindrical pin 5*25	*	*	HY11702
118	Fuel cap washer	*	*	HY11801
119	Fuel cap	*	*	HY11903
120	Front handle	*	*	HY12001
121	The cover of front handle	*	*	HY12101
122	Brake guard	*	*	HY12201
128	Top cover	*	*	HY12804
130	Air cleaner-down	*	*	HY13004
131	on/off switch	*	*	HY13102
133	Muffler cover	*	*	HY13303
135	Muffler	*	*	HY13508
136	Muffler paper pad	*	*	HY13601
137	Square-head bolt 5*100	*	*	HY13701
139	Ignition	*	*	HY13904
140	Spark plug	*	*	BPMR7A
141	Cylinder	*		HY14107
	Cylinder		*	HY14105
142	Bolt M5*22	*	*	HY14201
143	Paper pad of inlet pipe	*	*	HY14304
144	Inlet pipe	*	*	HY14401
146	Inlet pipe rack	*	*	HY14601
147	Adjust gear clip sleeve	*	*	HY14702
148	Choke rod sleeve	*	*	HY14801
149	Choke rod	*	*	HY14904
150	Paper pad of inlet pipe rack	*	*	HY15004
151	Inlet flange	*	*	HY15101

152	Copper ring	*	*	HY15201
153	Carburetor	*	*	HY15306
155	Inlet elbow	*	*	HY15502
157	Carburetor seat damping	*	*	HY15701
159	Guide bar 16	*		HY15901
	Guide bar 18		*	HY15902
160	Chain 16" 3/8	*		HY16001
	Chain 18" 3/8		*	HY16002
162	Cylindrical pin 2*30	*	*	HY16201
167	Recoil complete	*	*	HY16709
198	Bearing 6202 open	*	*	HY19802
235	Brake guard fixing sleeve	*	*	HY23502
236	Brake guard fixing block	*	*	HY23602
237	Short damping	*	*	HY23702
244	Brake spring	*	*	HY24401
249	Torison spring	*	*	HY24901
255	Oil seal cap cover	*	*	HY25501
256	Oil seal 15*28*5	*	*	HY25601
258	Dust guard plate	*	*	HY25801
262	Choke plate	*	*	HY26201
265	Suction pipe	*	*	HY26501
272	Cylindrical pin 6*28	*	*	HY27201
277	Oil inlet pipe	*	*	HY27701
279	Housing clip	*	*	HY27901
280	Wind block	*	*	HY28002
284	Short damping	*	*	HY28401
301	Spark plug cover	*	*	HY30102
303	Carburetor seat	*	*	HY30301
305	Air cleaner lock	*	*	HY30501
361	Primer	*	*	HY36101