




Diagram No.	part No.	Part name	Qty
1	6360.3.000200	base board	1
2	6301.4.000200	base rubber	2
3	7.01.00000300	Hexagon flange bolt	2
4	6301.4.000100	oil drainage plug	1
5	7.02.00000501	square nut	8
6	7.02.00000101	spring nut	10
7	636N.5.000100	lower bracket - inverter	1
8	6701.4.000700	tank rubber	4
9	7.01.00002000	Hexagon flange bolt	19
10	6360.5.000100	wheel axle	1
11	7.03.00002300	cross recess pan head screw	5
12	6360.3.000300	wheel	2
13	7.06.00001900	washer	2
14	7.06.00004600	retainer ring	2
15	6361.5.000200	battery bracket	1
16	6360.7.004700	sponge	1
17	7.03.00003900	cross recess pan head screw	1
18	64F10055.6.000300	battery	1
19	6361.5.000500	press plate	1
20	6360.7.004800	sponge	2
21	7.01.00000100	Hexagon flange bolt	2
22	6367.0.000100	engine assembly	1
23	6360.5.000300	frame	1
24	6305.5.000600	rectifier mounting	1
25	6101.6.001700	rectifier	1
26	7.03.00002000	cross recess pan head screw	1
27	7.02.00000200	Hexagon nut	1
28	6361.5.000400	fuel tank	1
29	6353.3.000100	fuel tank filter	1
30	7.06.00003100	spring washer	6
31	7.01.00004300	Hexagon flange bolt	6
32	6361.4.000200	fuel tube	1
33	6326.5.000500	fuel tube protective spring	2
34	6326.5.001700	clamp	1
35	6201.5.001000	clapm	3
36	6301.3.002800	fuel filter	1
37	6361.4.000300	fuel tube	1
38	6329.3.000100	fuel tap mounting plate	1
39	7.03.00009600	cross recess pan head screw	2
40	6326.5.001500	fuel tap	1
41	6361.4.000100	fuel tube	1
42	6326.5.000300	clamp	3
43	6101.4.001100	fuel tube	1
44	9.303.6.000700	Ignition Coil	1
45	6361.5.000900	starting control panel	1
46	6337.6.000500	rocker switch	1
47	6101.3.002200	fuel tap knob	1
48	7.03.00002100	cross recess pan head screw	1
49	6360.5.000400	pulling rod assembly	1
50	6360.5.001300	cross bar	2
51	6360.4.000300	sponge sleeve	2
52	6360.3.001800	connecting part	2
53	6360.3.001900	connecting part	2
54	7.03.00001200	cross recess sink head screw	4
55	7.01.00001700	Hexagon flange bolt	16
56	6353.5.000700	starting controller bracket	1

INVERTER GENERATOR

MODEL : HY4500i

Diagram No.	part No.	Part name	Qty
57	630H.2.000400	inverter moduel	1
58	7.01.00002900	Hexagon flange bolt	6
59	6331.6.002600	starting controller	1
60	6701.5.002200	bushing	2
61	6367.3.000200	right housing	1
62	6201.5.000600	recoil handle mounting plate	1
63	7.06.00001300	washer	2
64	7.08.00000100	rivet	2
65	6205.5.000200	recoil handle decorative cover	1
66	6201.4.001300	rubber bushing	1
67	6720.4.000100	wire protective sleeve	2
68	6201.3.001400	recoil handle	1
69	6232.3.000400	recoil handle cover	1
70	7.03.00000100	cross recess pan head screw	1
71	6367.3.001000	engine oil service panel	1
72	6360.7.002100	sponge	1
73	6360.3.002100	lock bolt	1
74	6367.3.000400	left housing	1
75	6360.7.003100	sponge	1
76	6201.7.000100	sponge	1
77	6367.3.000800	air cleaner service panel	1
78	6360.7.002000	sponge	1
79	7.03.00000800	cross recess pan head screw	8
80	6367.3.000600	top housing	1
81	6360.7.003200	sponge	2
82	6360.7.003300	sponge	2
83	6360.7.003400	sponge	1
84	6360.4.000400	fuel split rubber	1
85	6360.3.000500	front housing	1
86	6360.7.002400	sponge	1
87	6360.7.002500	sponge	1
88	6360.7.002600	sponge	1
89	6361.3.000600	battery sercive cover	1
90	6361.7.001000	sponge	1
91	6361.5.000700	decorative cover	2
92	6360.3.001400	muffler cover	1
93	6360.7.003500	sponge	1
94	6360.7.003600	sponge	1
95	6301.4.001000	muffler cover rubber	1
96	636V.5.000100	control panel assembly	1
97	7.03.00002200	cross recess pan head screw	6
98	7.06.00000600	tab washer	1
99	7.06.00000500	washer	1
100	7.06.00000800	spring washer	1
101	7.02.00000200	Hexagon nut	1
102	6101.6.000900	ECO switch	1
103	6101.3.003400	weather proof cover	1
104	6301.6.002400	Display panel group	1
105	7.02.00003200	spring nut	1
106	6101.6.001100	reset button	1
107	6116.5.000100	DC socket washer	1
108	6116.6.000500	DC socket	1
109	6318.6.000200	DC breaker	1
110	6101.6.000800	AC socket	2
111	7.03.00001200	cross recess pan head screw	8
112	6331.6.000500	overload protector	2
113	60JD.6.000101	ignitor	1




Diagram No.	part No.	Part name	Qty
1	G5787-06012-00	BOLT , FLANGE , M6X14	6
2	12310-210V101-00	COVER ASSY., HEAD	1
3	12391-210V101-00	PKG , HEAD COVER	1
4	G5789-08060-00	BOLT , FLANGE , M6X80	4
5	12210-210V201-00	HEAD COMP., CYLINDER	1
6	90043-06095-00	BOLT , STUD	2
7	94301-10016-00	PIN , DOWEL	1
8	12251-170101-00	GASKET , CYLINDER HEAD	1
9	98097-188201-00	SPARK PLUG F7RTC	1
10	90047-08038-00	BOLT , STUD	2
11	14781-168201-00	Locker , VALVE	4
12	14771-168201-00	RETAINER , VALVE SPRING	2
13	14751-168101-00	SPRING , VALVE	2
14	12209-168201-00	SEAL , VALVE STEM	1
15	14721-210V201-00	VALVE , EX.	1
16	14711-210V201-00	VALVE, INLET	1
17	14700-210V101-00	VALVE KIT	1
18	1443A-210V101-00	SHAFT , VALVE ROCKER	2
19	14431-210V101-00	ARM , VALVE ROCKER	2
20	14440-210V101-00	ROD , PUSH	2
21	14441-210V101-00	LIST , VALVE	2
22	13200-225101-00	ROD ASSY., CONNECTING	1
23	90551-168201-00	CLIP , PISTON PIN	2
24	13010-170201-00	RING SET , PISTON	1
25	13101-170B101-00	PISTON	1
26	13111-168201-00	PIN , PISTON	2
27	90131-10015-00	BOLT , DRAIN PLUG	2
28	90601-10200-00	WASHER , DRAIN PLUG	2
29	12000-170B101-00	CRANKCASE	1
30	96100-6205201-00	BEARING	2
31	15510-168101-00	SWITCH ASSY. , OIL LEVEL	1
32	13310-225101-00-B1	CRANK SHAFT COMP	1
33	14100-168101-00	CAMSHAFT ASSY.	1
34	94301-08014-00	PIN , DOWEL	2
35	11381-170B101-00	PACKING , CASE COVER	1
36	15600-168101-00	OIL FILLER CAP ASSY	1
37	11300-170B203-00	CASE COVER	1
38	91202-254106101-00	OIL SEAL	2
39	G5789-08032-00	BOLT , FLANGE , M8X32	6
40	16212-210V101-00	PACKING , CARBURETOR	1

Diagram No.	part No.	Part name	Qty
41	16570-210V101-00	INSULATOR , CARBURETOR	1
42	16221-168101-00	PACKING , CARBURETOR	1
43	16100-60Q201-00	CARBURETOR	1
44	16269-168205-00	PACKING , CARBURETOR	1
45	G6177-06000-00	NUT , FLANGE , M6	2
46	17250-G10102-00-EPA	AIR CLEANER	1
47	15721-168102-00	Tube, Breather	1
48	63015001600	muffler shield	1
49	63014000400	shock absorber	4
50	70200001900	nut, M8	6
51	70100000800	Hexagon flange bolt	4
52	70100001100	Hexagon flange bolt	1
53	93035003500	centrifugal fan	1
54	70600004701	washer, 8*28*3	1
55	70100008200	Hexagon bolt, M8×1×25	1
56	18381-168101-00	GASKET , CYLINDER	1
57	93005002900	muffler complete	1
58	G6170-08000-00	NUT , FLANGE , M8	2
59	63013000400	muffler housing	1
60	70100005400	Hexagon flange bolt, M6×16	12
61	93703000200	cylinder head air flow shield	1
62	G5787-06012-00	BOLT , FLANGE , M6X12	12
63	93703000100	upper shield	1
64	70100001000	Hexagon flange bolt, M8×16	2
65	93033000900	back shield	1
66	63013003200	oil draining rubber guide	1
67	93705000600	stator liner	4
68	63611000100	stator	1
69	70100009600	bolt, M6×60	4
70	64201000200	rotor	1
71	2630101572	NUT , FLANGE M16	1
72	93036000300	trigger	1
73	25204000300-1	impeller	1
74	28451-208120-00	PULLEY , STARTER	1
75	19610-170103-00-F	Blower Housing	1
76	63015001700	engine mounting - left	1
77	63015001800	engine mounting - right	1
78	70100011000	Hexagon flange bolt, M8×30	4
79	67046001500	stepmotor	2
80	70300008700	cross recess pan head screw	4